

Push-In Fitting Incorporated Type Solenoid Valve Solenoid Valve SVA21 Series

• Lightweight and Large Capacity

 Effective Sectional Area 18mm² (Cv 0.97) with valve width 16mm (5/8")

Various Valve Selections

Solenoid Valve SVA21 Series

- Characteristics
 - •2 selections of piping direction: (Top and Side)

•2 color selection: Black and Light Gray

 Twin 3-Port Solenoid Valve (3-way valve) enables to control 2 actuators separately with one unit.

Vacuum-operatable 2 / 3-Port Solenoid Valve_____

- Vacuum-operatable 2 or 3-way valve which does not require external piping.
- •Single and Double solenoid types are available

PISCO



1) Output Port Size, 2) Inlet Port Size (*)

Fitting Type	Push-In Fitting (inch)						Push-In Fitting (mm)					
Code	1/4C	5/16C	3/8C	1/4L	5/16L	3/8L	6C	8C	0C	6L	8L	0L
Size O.D.	ø1/4"	ø5/16"	ø3/8"	ø1/4"	ø5/16"	ø3/8"	ø6	ø8	ø10	ø6	ø8	ø10
Piping Direction		Side		Тор	(Elbov	v)		Side		То	p (Elbo	w)

* When the silencer exhaust is selected, the inlet port piping option is only "Side" (straight fitting).

③ Exhaust Port

Fitting Type	Push-In Fitting (mm)			Push	n-In Fitting (i	Silencer (Open-Air Exhaust)	
Code	1/4	5/16	3/8	6	8	0	S
Size O.D.	ø1/4"	ø5/16"	ø3/8"	ø6	ø8	ø10	—

* Piping direction of exhaust ports are the same style as the inlet port. If you choose "Top" direction of inlet port (elbow type), the exhaust ports come with all "Top" directions (elbows).

* Do not plug the exhaust ports even when you choose T or U type of valve (2-way valve) since the pilot valve air exhausts through the ports.

4 Valve Type

Code	Position	Port	Valve Function	Code	Position	Port	Valve Function
S	2	5	Single Solenoid	Α	3	5	Closed Center
D	2	5	Double Solenoid	R	3	5	Exhaust Center
E	2	3	4(A).2(B).Normally Closed (Twin 3-way valve)	Ρ	3	5	Pressure Center
F	2	3	4(A).2(B).Normally Open (Twin 3-way valve)	Т	2	2	Single Solenoid (Vacuum-operatable valve)
G	2	3	4(A).Normally Closed, 2(B).Normally Open	U	2	2	Double Solenoid (Vacuum-operatable valve)
Н	2	3	4(A).Normally Open, 2(B).Normally Closed	V	2	3	Single Solenoid (Vacuum-operatable valve)
				W	2	3	Double Solenoid (Vacuum-operatable valve)

(5) Color

B : Black

W: Light Gray

⁽⁶⁾ Valve Coil Voltage

D24: DC24V

100: AC100V

Solenoid Valve SVA21 Series

Model Designation of Mounting Unit (Example)



1 Valve Type

Code	Position	Port	Valve Function	Code	Position	Port	Valve Function
S	2	5	Single Solenoid	Α	3	5	Closed Center
D	2	5	Double Solenoid	R	3	5	Exhaust Center
Е	2	3	4(A).2(B).Normally Closed (Twin 3-way valve)	Ρ	3	5	Pressure Center
F	2	3	4(A).2(B).Normally Open (Twin 3-way valve)	Т	2	2	Single Solenoid (Vacuum-operatable valve)
G	2	3	4(A).Normally Closed, 2(B).Normally Open	U	2	2	Double Solenoid (Vacuum-operatable valve)
Н	2	3	4(A).Normally Open, 2(B).Normally Closed	V	2	3	Single Solenoid (Vacuum-operatable valve)
				W	2	3	Double Solenoid (Vacuum-operatable valve)

Valve Coil Voltage

D24: DC24V

100:AC100V

③ Color

B: Black

W: Light Gray

Sub-Base Specifications

Fluid Medium		A	lir
Operating Pres	sure Range	30~100psi (0.2~0.7MPa)
Pressure Resis	tance	150psi (1.05MPa)
Operating Tem	p. Range	40~ 120°F	= (5∼50°C)
Installing Direc	tion	No Restr	iction (*1)
No. Mountable	Main Valve	1 ι	unit
			Ø1/4", 6mm (*2)
Tubo Dia	Port	Push-In Fitting	ø5/16", 8mm (*2)
Tube Dia.	1 OIL		ø3/8", 10mm (*2)
	4(A).2(B) port	Push-In Fitting ≑ ø5/32"、ø1/4"、ø	5/16"、Ø 4mm、Ø6mm、Ø8mm
Wiring Mothod	Туре	Individual Plug	g-in Connector
wining method	No. of Pins	3 p	bins
Silencer		Standard equipment only with open	-air exhaust (5(R1) and 3(R2) Port).

*1. Refer to "Warning" in "Detailed Safety Instructions".

Solenoid Valve Specifications (DC24V)

$\overline{}$	Model	SVA 21S-D24	SVA 21D-D24	SVA 21A-D24	SVA 21E-D24	SVA 21T-D24	SVA 21U-D24	SVA 21V-D24	SVA 21W-D24
				SVA 21R-D24	SVA 21F-D24				
				SVA 21P-D24	SVA 21G-D24				
Item					SVA 21H-D24				
	Valve Type				Direct Ac	ting Valve			
	Valve Stracture			Ela	stic Seal,	Poppet Va	alve		
	Rated Coil Voltage				DC	24V			
Dilot Volvo	Tolerance of Voltage Range				DC21.6	\sim 26.4V			
PIIOL Valve	Power Consumption				1.2W (w	ith LED)			
	Surge Protection Circuit				Dic	ode			
	Manual Operation			N	lon-Lock F	Push Butto	'n		
	Operating Pressure Range			30	~100psi ((0.2~0.7N	1Pa)		
	Valve Type			Pneuma	atic Opera	tion by Pil	ot Valve		
	Valve Stracture			Ela	astic Seal	,Spool Va	lve		
	Number of Positions	2-Po:	sition	3-Position		2-Position			
	Number of Ports		5-Port		3-Port × 2 (*1)	2-F	Port	3-F	ort
	Valve Function	Single Solenoid	Double	Solenoid	Single Solenoid × 2	Single Solenoid	Double Solenoid	Single Solenoid	Double Solenoid
Main Valve	# of pilot points	1		2		1	2	1	2
	Response Time (*2)	18msec	12msec	18m	nsec		15m	nsec	
	Max. Operation Cycle				51	Ηz			
	Min. Excitation Time		50msec				50msec		50msec
	Lubrication				Not Re	quired			
	Operating Pressure Range	30~	100psi (0	.2~0.7M	IPa)	-14.5	~100psi (·	-0.1 ~ 0.7	'MPa)

*1. This is a valve construction incorporating 2 \times 3-port valves. 1(P) is common.

*2. Values are at air pressure of 0.5MPa (72psi) and from power off to on. For 3 positions valve, the valueis from neutral position of all port block (closed center) valve.

Solenoid Valve SVA21 Series

Solenoid Valve Specifications (AC100V)

$\overline{}$	Model	SVA 21S-100	SVA 21D-100	SVA 21A-100	SVA 21E-100	SVA 21T-100	SVA 21U-100	SVA 21V-100	SVA 21W-100
	_			SVA 21R-100	SVA 21F-100				
				SVA 21P-100	SVA 21G-100				
Item					SVA 21H-100				
	Valve Type				Direct Ac	ting Valve			
	Valve Stracture			Ela	stic Seal,	Poppet Va	alve		
	Rated Coil Voltage				AC1	00V			
Dilat Valva	Tolerance of Voltage Range				AC90 -	~ 110V			
Pliut valve	Power Consumption				1.5VA (w	/ith LED)			
	Surge Protection Circuit				Dic	ode			
	Manual Operation			N	lon-Lock F	Push Butto	n		
	Operating Pressure Range			30~	-100psi (0	0.2~0.7M	Pa)		
	Valve Type			Pneuma	atic Opera	tion by Pil	ot Valve		
	Valve Stracture			Ela	astic Seal,	Spool Va	lve		
	Number of Position	2-Po	sition	3-Position			2-Position		
	Number of Ports		5-Port		3-Port × 2 (*1)	2-F	Port	3-F	ort
	Valve Function	Single Solenoid	Double	Solenoid	Single Solenoid × 2	Single Solenoid	Double Solenoid	Single Solenoid	Double Solenoid
Main Valve	# of pilot points	1		2		1	2	1	2
	Response Time (*2)	18msec	12msec	18m	nsec		15m	nsec	
	Max. Operation Cycle				51	Ηz			
	Min. Excitation Time		50msec				50msec		50msec
	Lubrication				Not Re	equired			
	Operating Pressure Range	30-	-100psi (0	0.2~0.7N	1Pa)	-14.5	i~100psi (-0.1 ~ 0.7	/MPa)

*1. This is a valve construction incorporating 2x3-port valves. 1(P) is common.

*2. Values are at air pressure of 72.5psi (0.5MPa) and from power-off to-on. For 3-positions valve, the value is from neutral position of all port block valve.

	Model	SVA 21S-	SVA 21D- 🗌	SVA 21A-	SVA 21E- 🗌	SVA 21T- 🗌	SVA 21V- 🗌
				SVA 21R-	SVA 21F- 🗌	SVA 21U- 🗌	SVA 21W-
				SVA 21P- 🗌	SVA 21G-		
Piping Spec.					SVA 21H- 🗌		
$1(D) \rightarrow 1(A) \ O(D) \ (\ \phi \ 2/8" \ 10mm)(*2)$	C (*3)	3.4	3.4	2.4	3	3.4	3.4
$\Gamma(F) \rightarrow 4(A). \Sigma(D) (\psi 3/6, TOTIIII)(\Sigma)$	S (*4)	17(0.92)	17(0.92)	12(0.65)	15(0.81)	17(0.92)	17(0.92)
1(D) = A(A) O(D) (A E (A C = Omm) (*O)	C (*3)	3.2	3.2	2.4	2.9	2.6	2.6
$1(P) \rightarrow 4(A). \geq (D) (\psi 5/10, OIIIII) (2)$	S (*4)	16(0.86)	16(0.86)	12(0.65)	14.5(0.78)	13(0.7)	13(0.7)
$1(D) = A(A) O(B) (\pm 1/4" \text{ Grave}) (*0)$	C (*3)	2.1	2.1	1.9	2.1	1.7	1.7
$(P) \rightarrow 4(A).2(D) (\psi 1/4, 011111) (2)$	S (*4)	10.5(0.56)	10.5(0.56)	9.5(0.51)	10.5(0.56)	8.5(0.46)	8.5(0.46)
4(A).2(B) (<i>φ</i> 3/8", 10mm) →	C (*3)	3.6	3.6	2.8	2.8		3.5
5(R1).3(R2)without Check Valve (*1)	S (*4)	18(0.97)	18(0.97)	14(0.75)	14(0.75)		17.5(0.95)
4(A).2(B) (φ5/16", 8mm)→	C (*3)						
5(R1).3(R2)with Check Valve (*1)	S (*4)						
4(A).2(B) (φ5/16", 8mm)→	C (*3)	3.4	3.4	2.7	2.7		2.8
5(R1).3(R2)without Check Valve (*1)	S (*4)	17(0.92)	17(0.92)	13.5(0.73)	13.5(0.73)		14(0.76)
4(A).2(B) (φ1/4", 6mm)→	C (*3)						
5(R1).3(R2)with Check Valve (*1)	S (*4)						
4(A).2(B) (φ1/4", 6mm)→	C (*3)	2.1	2.1	2	2		1.9
5(R1).3(R2)without Check Valve (*1)	S (*4)	10.5(0.56)	10.5(0.56)	10(0.54)	10(0.54)		9.5(0.51)

Flow Characteristics

*1. The value of .5(R1) and 3(R2) port are those of Open-air Exhaust.

*2. 2(B) to 4(A) piping is applied to valve type T / U / V / W.

*3. C: Sonic Conductance C(dm3/(s-bar)

*4. S: Effective Sectional Area S(mm²(CV))

Cylinder Speed Table

	1									
	Cylinder Tube bore (mm)									
Cylinder Speed (m/s)	<i>ф</i> 20	<i>ф</i> 25	<i>ф</i> 32	<i>ф</i> 40	<i>ф</i> 50	<i>ф</i> 63	φ80	<i>ф</i> 100	¢ 125	¢140
100										
200										
300										
400										
500										
600										
700										
800										

Note) The average speed of the cylinder represents a reference value where the pressure is 0.5MPa (72psi), the load factor is 30% and the piping tube length is 1m.

• Cylinder speed can vary depending on the piping and joint configurations.

• The table represents the case that Ø8mm Push-In Fitting is used on 4(A) and 2(B) ports of SVA21S-D24.

Solenoid Valve SVA21 Series

Construction

Electric Circuit





Weight List

Valve Type	Weight (g)	Valve Type	Weight (g)		Weight (g)	Cartridge Fitting	Weight (g)
SVA 21S	85.5	SVA 21P	131	Sub Base	52.5	CJC 18-06	20.5
SVA 21D	129	SVA 21R	131			CJC 18-08	20
SVA 21E	131	SVA 21T	81.5	Silencer Unit	Weight (g)	CJC 18-10	19
SVA 21F	131	SVA 21U	125	Port Ø 6mm	28	CJL 18-06	23
SVA 21G	131	SVA 21V	81.5	Port ϕ 8mm	22.5	CJL 18-08	25
SVA 21H	131	SVA 21W	125	Port Ø 10mm	27	CJL 18-10	31.5
SVA 21A	131.5						

Use the following formula to calculate the weight of SVA21.

Sub-Base + (Cartridge Fitting x Qty) + Silencer Unit + Valve Type

Example SVA 21 - OCOC S - S B - D24

52.5 + 38 + 27 + 129 = 246.5g

- ① Sub-Base : 52.5g
- O Cartridge Fitting (CJC 18-10) \vdots 19g $\times 2$
- ③ Silencer Unit (Ø10mm) : 27g
- ④ Valve Type (SVA 21D):129g

▲ Detailed Safety Instructions

Before using PISCO products, be sure to read "Safety Instructions" and "Safety Instruction Manual" and "Common Safety Instructions for Solenoid Valve Series".

Warning

- 1. When a solenoid valve is operated under a vibration of 49m/s² or less, install a spool valve at a right angle to the vibrating direction.
 - * Refer to "4. Installation" in "Precautions for Use".

Caution

- Do not use a 3-position valve for middle-position stop of the cylinder that requires accuracy. Compressiveness of air does not achieve accuracy in stop position. Also, the valve permits leakage, so that retention of stop position for long term may not be possible.
- 2. Do not give excessive tension or bending to the individual plug-in connector (cable). Disconnection or damage to the connector may be caused.
- 3. The cartridge joint can be disconnected by removing the lock pin. During use, however, make certain that the lock pin is properly in place.
- 4. Read the manual carefully for proper installation and removal of valves. Also, keep the manual at hand.
- 5. Thoroughly read the method for replacing and piping Cartridge Fittings in this catalog.

▲ Safety Instructions for Vacuum-Operateble 2 / 3-Port Solenoid Valve

- Connect 2(B) Port with air supply port and 4(A) Port with an actuator port. The reverse connection causes troubles.
- Place a filter to prevent foreign particles from entering inside.

Solenoid Valve SVA21 Series

Standard Size List

Туре	Port	Fitting Type	Tube O.D.	Туре	Port	Fitting Type	Tube O.D.
SVA Double Solenoid Valve Tube Exhaust	Output port 4(A) 2(B)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm	SVA Single Solenoid Valve Tube Exhaust	Output port 4(A) 2(B)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm
	1(P) Exhaust port 5(R1) 3(R2)	Push-In Fitting (Straight Type / Elbow Type)	ø5/16 ø3/8 ø6mm ø8mm ø10mm		1(P) Exhaust port 5(R1) 3(R2)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm
Туре	Port	Fitting Type	Tube O.D.	Туре	Port	Fitting Type	Tube O.D.
SVA Double Solenoid Valve Open-air Exhaust	Output port 4(A) 2(B)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm	SVA Single Solenoid Valve Open-air Exhaust	Output port 4(A) 2(B)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm
	Inlet port 1(P)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm		Inlet port 1(P)	Push-In Fitting (Straight Type / Elbow Type)	ø1/4 ø5/16 ø3/8 ø6mm ø8mm ø10mm

Tube Exhaust



SVA Single Solenoid Valve Tube Exhaust

SVA21- 🗌 🗌 - S 🗌 - 🛄	
SVA21SV	VA-044
SVA21	





Solenoid Valve SVA21 Series

Open-air Exhaust



SVA Single Solenoid Valve Open-air Exhaust (Silencer Exhaust)

Model Code	CAD file name
SVA21- S-S	
SVA21- 🗌 S-T 🗌 - 🗌	SVA-046
SVA21- S-V	





Dimension of Fitting Part

Unit : mm

Piping Direction: Side	Piping Direction: Top			Inlet port - 1(P) Port and			
Outlet ports - 4(A) · 2(B) Port,	Outlet ports - 4(A) · 2(B) Port,		Silencer (Open-air Exhaust)				
Inlet/Exhaust ports - 1(P) · 5(R1) ·	Inlet/Exhaust ports - 1(P) · 5(R1) ·						
3(R2) Port (Tube Exhaust)	3(R2) Port (Tube Exhaust)						
Tube O.D.	Tube O.D.		Tube O.D. øD		С		
ØD L C	øD		L2	C	6(1/4)	7	17
6(1/4) 11 17	6(1/4)	14	20	17	8(5/16)	5	18.5
8(5/16) 12.5 18.5	8(5/16)	17	23	18.5	10(3/8)	5.5	20.5
10(3/8) 15 21	10(3/8)	21	26.5	20.5			

Replacement of Silencer Element



To replace silencer element for 21 series with openair exhaust, loose the installing screws of the element cover with a proper Phillips head screwdriver, and take out the cover for the replacement.

Model Designation	Adapted Model	Quantity
SVA21EX-E	SVA21 (Open-air exhaust)	2pcs / set

Solenoid Valve SVA21 Series

Construction of SVA 21 Series (Stand-alone Unit) Tube Exhaust Type



Construction of SVA 21 Series (Stand-alone Unit) Open-air Exhaust Type



▲ SAFETY Instructions

This safety instructions aim to prevent personal injury and damage to properties by requiring proper use of PISCO products.

Be certain to follow ISO 4414 and JIS B 8370

ISO 4414 : Pneumatic fluid power…Recomendations for the application of equipment to transmission and control systems.

JIS B 8370 \vdots General rules and safety requirements for systems and their components.

This safety instructions is classified into "Danger", "Warning" and "Caution" depending on the degree of danger or damages caused by improper use of PISCO products.

Danger Hazardous conditions. It can cause death or serious personal injury.

Warning Hazardous conditions depending on usages. Improper use of PISCO products can cause death or serious personal injury.

Accuration Hazardous conditions depending on usages. Improper use of PISCO products can cause personal injury or damages to properties.

\land Warning I

- 1. Selection of pneumatic products
 - ① A user who is a pneumatic system designer or has sufficient experience and technical expertise should select PISCO products.
 - ② Due to wide variety of operating conditions and applications for PISCO products, carry out the analysis and evaluation on PISCO products. The pneumatic system designer is solely responsible for assuring that the user's requirements are met and that the application presents no health or safety hazards. All designers are required to fully understand the specifications of PISCO products and constitute all systems based on the latest catalog or information, considering any malfunctions.
- 2. Handle the pneumatic equipment with enough knowledge and experience
 - Improper use of compressed air is dangerous. Assembly, operation and maintenance of machines using pneumatic equipment should be conducted by a person with enough knowledge and experience.
- 3. Do not operate machine / equipment or remove pneumatic equipment until safety is confirmed.
 - ① Make sure that preventive measures against falling work-pieces or sudden movements of machine are completed before inspection or maintenance of these machine.
 - ② Make sure the above preventive measures are completed. A compressed air supply and the power supply to the machine must be off, and also the compressed air in the systems must be exhausted.
 - ③ Restart the machines with care after ensuring to take all preventive measures against sudden movements.



Disclaimer 🔳

- 1. PISCO does not take any responsibility for any incidental or indirect loss, such as production line stop, interruption of business, loss of benefits, personal injury, etc., caused by any failure on use or application of PISCO products.
- PISCO does not take any responsibility for any loss caused by natural disasters, fires not related to PISCO products, acts by third parties, and intentional or accidental damages of PISCO products due to incorrect usage.
- 3. PISCO does not take any responsibility for any loss caused by improper usage of PISCO products such as exceeding the specification limit or not following the usage the published instructions and catalog allow.
- PISCO does not take any responsibility for any loss caused by remodeling of PISCO products, or by combinational use with non-PISCO products and other software systems.
- 5. The damages caused by the defect of Pisco products shall be covered but limited to the full amount of the PISCO products paid by the customer.

▲ SAFETY INSTRUCTION MANUAL

PISCO products are designed and manufactured for use in general industrial machines. Be sure to read and follow the instructions below.

\land Danger 🗖

- 1. Do not use PISCO products for the following applications.
 - ① Equipment used for maintaining / handling human life and body.
 - ② Equipment used for moving / transporting human.
 - 3 Equipment specifically used for safety purposes.

▲ Warning |

- 1. Do not use PISCO products under the following conditions.
 - Beyond the specifications or conditions stated in the catalog, or the instructions.
 - ② Under the direct sunlight or outdoors.
 - ③ Excessive vibrations and impacts.
 - ④ Exposure / adhere to corrosive gas, inflammable gas, chemicals, seawater, water and vapor. *
 * Some products can be used under the condition above(④), refer to the details of specification and condition of each product.
- 2. Do not disassemble or modify PISCO products, which affect the performance, function, and basic structure of the product.
- 3. Turn off the power supply, stop the air supply to PISCO products, and make sure there is no residual air pressure in the pipes before maintenance and inspection.
- 4. Do not touch the release-ring of push-in fitting when there is a working pressure. The lock may be released by the physical contact, and tube may fly out or slip out.
- 5. Frequent switchover of compressed air may generate heat, and there is a risk of causing burn injury.
- 6. Avoid any load on PISCO products, such as a tensile strength, twisting and bending. Otherwise, there is a risk of causing damage to the products.
- 7. As for applications where threads or tubes swing / rotate, use Rotary Joints, High Rotary Joints or Multi-Circuit Rotary Block only. The other PISCO products can be damaged in these applications.
- 8. Use only Die Temperature Control Fitting Series, Tube Fitting Stainless SUS316 Series, Tube Fitting Stainless SUS316 Compression Fitting Series or Tube Fitting Brass Series under the condition of over 60°C (140° F) water or thermal oil. Other PISCO products can be damaged by heat and hydrolysis under the condition above.
- 9. As for the condition required to dissipate static electricity or provide an antistatic performance, use EG series fitting and antistatic products only, and do not use other PISCO products. There is a risk that static electricity can cause system defects or failures.
- 10. Use only Fittings with a characteristic of spatter-proof such as Antispatter or Brass series in a place where flame and weld spatter is produced. There is a risk of causing fire by sparks.
- 11. Turn off the power supply to PISCO products, and make sure there is no residual air pressure in the pipes and equipment before maintenance. Follow the instructions below in order to ensure safety.
 - ① Make sure the safety of all systems related to PISCO products before maintenance.
 - ② Restart of operation after maintenance shall be proceeded with care after ensuring safety of the system by preventive measures against unexpected movements of machines and devices where pneumatic equipment is used.
 - ③ Keep enough space for maintenance when designing a circuit.
- 12. Take safety measures such as providing a protection cover if there is a risk of causing damages or fires on machine / facilities by a fluid leakage.



▲ Caution

- 1. Remove dusts or drain before piping. They may get into the peripheral machine / facilities and cause malfunction.
- 2. When inserting an ultra-soft tube into push-in fitting, make sure to place an Insert Ring into the tube edge. There is a risk of causing the escape of tube and a fluid leakage without using an Insert Ring.
- 3. The product incorporating NBR as seal rubber material has a risk of malfunction caused by ozone crack. Ozone exists in high concentrations in static elimination air, clean-room, and near the high-voltage motors, etc. As a countermeasure, material change from NBR to HNBR or FKM is necessary. Consult with PISCO for more information.
- 4. Special option "Oil-free" products may cause a very small amount of a fluid leakage. When a fluid medium is liquid or the products are required to be used in harsh environments, contact us for further information.
- 5. In case of using non-PISCO brand tubes, make sure the tolerance of the outer tube diameter is within the limits of Table 1.

mm size	Nylon tube	Polyurethane tube	inch size	Nylon tube	Polyurethane tube
Ø1.8mm	—	\pm 0.05mm	Ø1/8	\pm 0.1mm	\pm 0.15mm
ø3mm	—	± 0.15mm	Ø5/32	\pm 0.1mm	\pm 0.15mm
Ø4mm	± 0.1mm	± 0.15mm	Ø3/16	± 0.1mm	\pm 0.15mm
ø6mm	\pm 0.1mm	± 0.15mm	Ø1/4	\pm 0.1mm	± 0.15mm
Ø8mm	± 0.1mm	± 0.15mm	Ø5/16	\pm 0.1mm	\pm 0.15mm
ø10mm	± 0.1mm	± 0.15mm	Ø3/8	\pm 0.1mm	± 0.15mm
ø12mm	\pm 0.1mm	± 0.15mm	Ø1/2	\pm 0.1mm	\pm 0.15mm
Ø16mm	\pm 0.1mm	± 0.15mm	Ø5/8	\pm 0.1mm	\pm 0.15mm

● Table 1. Tube O.D. Tolerance

- 6. Instructions for Tube Insertion
 - ① Make sure that the cut end surface of the tube is at right angle without a scratch on the surface and deformations.
 - ② When inserting a tube, the tube needs to be inserted fully into the pushin fitting until the tubing edge touches the tube end of the fitting as shown in the figure below. Otherwise, there is a risk of leakage.





Tube is not fully inserted up to tube end.

- ③ After inserting the tube, make sure it is inserted properly and not to be disconnected by pulling it moderately.
- **. When inserting tubes, Lock-claws may be hardly visible in the hole, observed from the front face of the release-ring. But it does not mean the tube will surely escape. Major causes of the tube escape are the followings;

①Shear drop of the lock-claws edge

② The problem of tube diameter (usually small)

Therefore, follow the above instructions from to , even lock-claws is hardly visible.

- 7. Instructions for Tube Disconnection
 - ① Make sure there is no air pressure inside of the tube, before disconnecting it.
 - ② Push the release-ring of the push-in fitting evenly and deeply enough to pull out the tube toward oneself. By insufficient pushing of the releasering, the tube may not be pulled out or damaged by scratch, and tube shavings may remain inside of the fitting, which may cause the leakage later.
- 8. Instructions for Installing a fitting
 - ① When installing a fitting, use proper tools to tighten a hexagonal-column or an inner hexagonal socket. When inserting a hex key into the inner hexagonal socket of the fitting, be careful so that the tool does not touch lock-claws. The deformation of lock-claws may result in a poor performance of systems or an escape of the tube.
 - ② Refer to Table 2 which shows the recommended tightening torque. Do not exceed these limits to tighten a thread. Excessive tightening may break the thread part or deform the gasket and cause a fluid leakage. Tightening thread with tightening torque lower than these limits may cause a loosened thread or a fluid leakage.
 - ③ Adjust the tube direction while tightening thread within these limits, since some PISCO products are not rotatable after the installation.

●Table 2:	Recommended	tightening	torque	/ Sealock	color /	Gasket
materials	6					

Thread type	Thread size	Tightening torque	Sealock color	Gasket materials	
	M3 imes 0.5	0.7N [.] m		01100004	
	M5 imes 0.8	1.0 ~ 1.5N [.] m	1.0 ~ 1.5N [.] m		
	M6 imes 1	2 ~ 2.7N [.] m			
Metric thread	M3 imes 0.5	0.5 ~ 0.6N [.] m	—	РОМ	
	M5 imes 0.8	1 ~ 1.5N∙m			
	M6 imes 0.75	0.8 ~ 1N [.] m			
	$M8 \times 0.75$	1 ~ 2N·m			
	R1/8	7 ~ 9N∙m		_	
Tonor nine thread	R1/4	12 ~ 14N·m	\A/bite		
laper pipe thread	R3/8	22 ~ 24N∙m	white		
	R1/2	28 ~ 30N·m			
Unified thread	No.10-32UNF	1.0 ~ 1.5N [.] m	—	SUS304、NBR	
National pipe thread taper	1/16-27NPT	7 ~ 9N∙m		_	
	1/8-27NPT	7 ~ 9N∙m			
	1/4-18NPT	12 ~ 14N m	White		
	3/8-18NPT	22 ~ 24N m			
	1/2-14NPT	28 ~ 30N·m	~ 30N·m		

- 9. Instructions for removing a fitting
 - ① When removing a fitting, use proper tools to loosen a hexagonal-column or an inner hex bolt.
 - ② Remove the sealant stuck on the mating equipment. The remained sealant may get into the peripheral equipment and cause malfunctions.
- 10. Arrange piping avoiding any load on fittings and tubes such as twist, tensile, moment load, shaking and physical impact. These may cause damages to fittings, tube deformations, bursting and the escape of tubes.

⚠ Common Safety Instructions for Solenoid Valve Series

Before selecting or using PISCO products, read the following instructions. Read the detailed instructions for individual series.

\land Warning

- 1. When piping, pipe flushing is required for pipes at both air supply and actuator sides. A filter (filtering accuracy should be 5μ m or less) should be located close to a solenoid valve on the upstream side. Drain or dust can cause malfunctions.
- 2. Do not supply compressed air or dry air more than necessary. Deterioration of seal rubber or oil can cause malfunctions.
- 3. Do not use a solenoid valve in the location where it is exposed to water, oil and dust falling. Using in such circumstance may cause malfunctions or damages, since the valve is neither drip- nor dust- proof. (Protection Structure: IP30)
- 4. Solennoid valve is not explosive-proof. Do not use a solenoid valve in the location it is exposed to inflammable and explosive gasses or liquid. Using in such circumstance can cause a fire or explosion.
- 5. Do not use a solenoid valve in the location where it is exposed to corrosive gas. Using in such circumstance can cause trouble.
- 6. Do not use a solenoid valve in the location where it is exposed excessive vibrating or shock. Using in such circumstance can cause malfunctions or trouble.
- 7. Make sure a leakage current is 1mA or less before starting the valve. A leakage current more than 1mA can cause malfunctions.
- 8. The coil in a valve generates heat by the following (1) to (3) conditions. Heating can impair the product life or cause problems in operation. Heating can also cause getting burnt or damaging peripheral machines.
 - Contact us when energization is necessary under the following conditions:
 - (1) The power is continuously on for more than 2 hours.
 - (2) High-cycle operation
 - (3) The total operation time per day is longer than non-operation time even the generator is operated intermittently.

- ▲ Caution
 - 1. A solenoid valve allows air leakage. Do not use the valve for applications which requires air tightness.
 - 2. Do not use a solenoid valve for a large air-blow. A drop of inner pressure can cause the internally pilotted-valve structure malfunctions.
 - 3. When a solenoid valve is switched over by a manual operation, connected actuators start operation. Confirm the safety before the system is operated.
 - 4. Make sure to turn off the power supply and wire colors before wiring.
 - 5. Solenoid valves work without lubrication. When lubrication is necessary, use Turbine Oil Class 1 (ISO VG 32). If lubrication is stopped in the middle of the operation, it can cause malfunctions due to the loss of initial lubricant on valves. Keep providing lubricant.
 - 6. Make sure each port by a marking on a solenoid valve body when piping.
 - 7. Turn off the power and air supply and make sure the residual pressure becomes zero before maintenance. It should be noted that the residual pressure exists between a solenoid valve and an actuator in Three-Position Closed Center type.
 - 8. Clogged element of a manifold with silencer increases the exhaust resistance. It can also cause impairing the performance in a whole pneumatic system. Carry out the maintenance periodically.
 - 9. Thoroughly read and understand instructions and precautions in this catalog before replacing a silencer element.